



Opsytec Dr. Gröbel

Opsytec Dr. Gröbel GmbH  
Am Hardtwald 6-8  
D-76275 Ettlingen

Phone: +49(0)7243 / 9 47 83-50  
Fax: +49(0)7243/ 9 47 83-  
65info@opsytec.de

# ***Radiometer RM-32***



## **Operating instructions**

Version: 1.4

# 1 Table of Contents

1	Table of contents .....	2
2	Change history .....	2
3	Symbol overview .....	2
4	Foreword.....	3
5	General description.....	4
6	Settings and connections .....	5
7	Programming the panelmeter.....	7
8	Integrated program routines.....	8
9	Communication RS232, RS485 or USB.....	11
10	Programming RS232, RS485 or USB .....	13
11	Sub-D RS232 Adapter .....	15
12	Technical data.....	16
13	Radiation protection .....	16

## 2 Change history

Version	Modified from	Changes
1.1	Paravia	div. adjustments
1.2	Paravia	enhanced communication
1.3	Paravia	Advanced preset RS232
1.4	Small	RS232 adapter board inserted

## 3 Symbol overview



Significance:  
Failure to follow the above instruction may result in injury to the user.



Significance:  
Failure to follow these instructions may result in damage to the unit.



Significance:  
Instruction is to be observed for regular operation.

## 4 Foreword

Dear Customer,

You have decided to purchase a high-quality precision UV measuring device.

The operation is simple, please follow exactly our explanations in the enclosed operating instructions, the measuring accuracy is then guaranteed.

In order to guarantee this measurement accuracy over a longer period of use, we recommend that you send your sensor to us for inspection every 12 months.

We recalibrate the sensor, if necessary we repair it. A short time later, your measuring equipment will be available again in mint condition with test certificate.

At the same time, we will keep you regularly informed about the latest UV measurement possibilities.

As you can see, customer service is still very important to us. We are happy to provide you with technical information and advice at any time.

Opsytec Dr. Gröbel GmbH

## 5 General description

The mains operated display unit RM-32 is designed for continuous monitoring of lamps mainly UV lamps. In addition to lamp monitoring, absorption, transmission and reflection measurements can also be carried out.

The display is digital (3 1/2 digits) in W/m<sup>2</sup>. Two light-emitting diodes (SP1, SP2) indicate the status in relation to two preselectable thresholds. Two relays with switching contacts are activated simultaneously. The relay functions can be triggered with a time delay.

The device is programmable and can control numerous parameters of the measurement process with its integrated measurement routines.


Optional USB, RS-232 or RS-485 interface is available.

Connect the supplied sensor to input 2 and 4. Only use the sensor type for which you ordered the device. Connecting a different sensor type can lead to malfunctions. Follow the instructions for the sensor carefully.

## 6 Settings and connections

### 2.1. Controls and display

The indicator lights up when the RM-32 is connected to mains voltage.



- MOD** enter or leave programming mode
- ▲** increment selected digit
- ◀** select next digit / position
- SP1** display threshold value of SP1 relay
- SP2** display threshold value of SP2 relay
- SP1** ● ON : SP1 relay contact is closed
- SP2** ● ON : SP2 relay contact is closed

Fig. 1: Control element RM32

SP1: When the button is pressed, the SP1 *pre-alarm* setpoint is displayed.

SP2: When the button is pressed, the SP2 *alarm* setpoint is displayed.

## 2.2 Terminal connection assignment




Fig. 2: Terminal assignment of the terminals

Relay SP2: potential-free switching output, alarm  
 Relay SP1: potential-free switching output, pre-alarm

PIN 9-11: RS232 output (optional via external board)  
Connect the circuit board with the sockets pointing downwards

PIN 12: + 24 V, wire colour white  
 PIN 13: 0V, wire colour brown  
 230V Mains: Mains voltage connection

Sensors with voltage output 0-10 V must be connected to the RM32 as follows:

Input 2: Sensor signal High , wire color black  
 Input 4: Sensor signal low, wire colour grey (GND for measurement)  
 24V output: galvanically isolated supply voltage 24V DC (max. 30 mA)

Sensors with current output 4-20mA must be connected to the RM32 as follows:

Brown / white at terminal number 12 (+ 24V)  
 Blue /black at terminal number 2 (input)

## 2.3 Locking the keypad

There is a jumper on the motherboard that can be placed through the hole in the side of the case. When the jumper is open, the keyboard is locked. An input of commands is then no longer possible.

## 7 Programming of the installation instrument

The programmable panelmeter RM-32 can control numerous parameters of the measuring sequence with its integrated measuring routines. New values are set via the keyboard.

**This way, the desired measuring routine can be selected at the RM-32:**

Press MOD button	MOD
Select routine with the arrow key	△
Confirm with MOD button	MOD

**Change values of the respective measuring routine:**

Set desired value with arrow key	△
Select next position with back arrow key	◀
Set desired value with arrow key,....	△

When the desired value is entered, Accept the value with the MOD key	MOD
---	-----

The device now operates in the measuring mode again.



Changes to the setting can greatly falsify the measurement result. Pay attention to the settings on delivery.

### 1. Error messages

If the measuring signal exceeds or falls below the permissible value of the input range, the following error message appears on the LED display:

"oooo" = measuring range is exceeded

"uuuu" = measuring range is undershot

## 8 Integrated program routines

### Routine 1-5: not occupied

### Routine 6: Set decimal point

The position of the decimal point on the LED display is set with

000: no decimal point (maximum display: 1999)  
001: 1.000  
002: 19.99  
003: 199.9

dialled.



Changes to routine 6 can strongly falsify the measurement result. Only change the settings of the device after consulting the manufacturer.

### Routine 7: Set switching point SP1 *pre-alarm*

With this function the threshold SP1 *pre-alarm* can be set in  $W/m.^2$ . The maximum value is 1000.

### Routine 8: Activate setpoint SP1 *pre-alarm*

This function routine can be used to switch the SP1 *pre-alarm* setpoint on and off. In the last digit

000: inactive or  
001: active  
set.

### Routine 9: Set switching point SP2 *alarm*

With this function the threshold SP2 *alarm* can be set in  $W/m.^2$ . The maximum value is 1000.

### Routine 10: Activate setpoint SP2 *alarm*

This function routine can be used to switch the SP2 *Alarm* setpoint on and off. In the last digit

000: inactive or  
001: active  
set.



**Routine 11: Switching point hysteresis SP1 *Pre-alarm***

The hysteresis is set in  $W/m.^2$

**Routine 12: Switching point hysteresis SP2 *Alarm***

The hysteresis is set in  $W/m.^2$

**Routine 15: Set relay function of SP1 *pre-alarm*****Routine 16: Set relay function of SP2 *alarm***

Each relay can act as a normally closed or normally open contact when the respective switching point is reached.

001: Opener  
000: N/O contact

NC contact = the relay opens the circuit when the switching point is reached.  
Normally open = the relay closes the circuit when the switching point is reached.

**Routine 17: Timed pickup or dropout delay of SP1 *pre-alarm***

When the threshold value is reached, the relay function is triggered with a time delay. The time delay is proportional to the number of measuring cycles (max. 1999 cycles). The measuring rate is 2.5 measurements per second.

Number of measuring cycles:     time delay

**Routine 18: Timed on-delay or off-delay of SP2 *alarm***

When the threshold value is reached, the relay function is triggered with a time delay. The time delay is proportional to the number of measuring cycles (max. 1999 cycles). The measuring rate is 2.5 measurements per second.

Number of measuring cycles:     time delay

**Routine 19: Querying the maximum measured value**

The maximum value is continuously determined and stored since the last RESET. The reset is carried out when the min. or max. value is displayed by pressing the SP1 *pre-alarm* and SP2 *alarm* keys simultaneously for 3 seconds.

**Routine 20: Querying the minimum measured value**

The minimum value is continuously determined and stored since the last RESET. The reset is carried out when the min. or max. value is displayed by pressing the SP1 *pre-alarm* and SP2 *alarm* keys simultaneously for 3 seconds.

**Routine 21: Last digit round up/down**

The value for the last decimal place can be rounded. The following settings are possible:

000: last digit is set to 0  
001: last digit is displayed  
002: last digit is set to 0 / 2 / 4 / 6 / 8  
005: last digit is set to 0 / 5

**Routine 22: Number of measurements for averaging**

The display shows the average value.

Setting

000: no averaging  
002: 2 measurements for average  
003: 3 measurements for average  
...  
1999: 1999 measurements for average

**Routine 23: not occupied**

Default setting: "000" must be maintained.

**Routine 24 and 25: not occupied****Routine 26: Divider factor of the measured value by 10**

Setting

000: no divisor factor  
001: Value is divided by 10

## 9 Communication RS232, RS485 or USB

### Data transmission of the measured values of the SPE670 via serial interface.

Routine 25: Activate/deactivate the serial interface  
 Routine 27: Setting the baud rate of the serial interface  
 Routine 34: Transmission cycles for the serial interface

Jumper JP4 can be used to bypass the enable/disable by routine 25, the interface is then always active. The cycle setting of routine 34 remains valid. Thus, the interface can still be deactivated by a transmission cycle of 0.

The individual characters are transmitted in ASCII code. The sign of the measured value is sent as a minus for negative values, otherwise as a space. The transmission starts with the first character of the day and ends with LF (line feed - 10d, 0Ah) and CR (carriage return - 13d, 0Dh) to start a new line at a connected printer or screen.

Day.Month.Year Std:Min  
 -measured value with decimal point

Dimension Designation Special purpose  
 DD.MM.YY SS:NN -XXX,XDBS

TT = Day 00 - 31  
 MM= month 00 - 12  
 JJ = Year 2000 - 2099  
 SS = Hour 0 - 23  
 NN = Minute 0 - 59

- = sign minus or space  
 XXX,X = measured value 0000 - 1999 with decimal point at correct position

D = dimension of the measured value m-milli, k-kilo,  
 B = Designation of the measured value V-Volt,  
 A-ampere, ...  
 S = User defined special character  
 . = point (ASCII - 2Eh, 46d)  
 : = colon (ASCII - 3Ah, 58d)  
 = Space (ASCII - 20h, 32d)  
 , = comma (ASCII - 2Ch, 44d)

Examples:

Telegram = 21.05.2001 13:15 1.234Bar

Characters	ASCII decimal
2	50
1	49
.	46
0	48
5	53
.	46
2	50
0	48
0	48
1	49
SP	32
1	49
3	51
:	58
1	59
5	53
SP	32
SP	32
1	49
,	44
2	50
3	51
4	52
B	66
a	97
r	114
LF	10
CR	13

**Example log with software hterm (not included):**

Received Data											
1	5	10	15	20	25	30	35	40	45	50	
0	6	.	0	5	.	2	0	0	0	0	V
0	6	.	0	5	.	2	0	0	0	0	V

## 10 Programming RS232, RS485 or USB

The RM-32 contains a Real Time Clock for value output via the serial interface. The following routines are only used with the option RS 232 output. With the help of the routines, different parameters can be controlled.

### **Routine 5: Setting (analog output) DAC 670 - 204 or RS232/RTC (670 - 232) built-in**

0 = DAC (670-204) or no extension  
1 = RS232/RTC (670-232) board (default)

### **Routine 25: Enable and time setting of the RS232**

000 = Locked,  
001 = Cycle time in min,  
002 = Cycle time in sec. (preset)

### **Routine 27: Setting the baud rate of the serial interface**

0 = 150,  
1 = 300,  
2 = 600,  
3 = 1200,  
4 = 2400  
5 = 4800, (Preset)  
6 = 9600 baud

### **Routine 28: Real-Time Clock Minutes**

This value is the minutes of the current time.  
Setting range: 0-59 minutes

### **Routine 29: Real-Time Clock Hours**

This value is the hours of the current time.  
Setting range: 0-23 o'clock

### **Routine 30: Real-Time Clock Date Tag**

This value is the day of the current date.  
Setting range: 1-31

### **Routine 31: Real-Time Clock Weekday**

This value is the day of the week of the current date.  
0 = Sunday  
1 = Monday  
..  
6 = Saturday

**Routine 32: Real-Time Clock Date-Month**

This value is the month of the current date. Setting range: 1-12

Ex.1 = January, ... 12 = December

**Routine 33: Real-Time Clock Date-Year**

This value is the low-order part of the year of the current date. The high-order part is always kept at 20. Setting range: 0-99

0 = 2000, .... 99 = 2099

**Routine 34 Transmission cycles for the serial interface**

At intervals of the set transmission cycles, the measured value is sent with date and time via the serial interface. The set number is evaluated in minutes and is the time interval between two transmission processes. Please note that the serial interface is generally enabled for transmission with routine 25.

must be. Setting range: 0-255

0 = Timer stop (no transmission)

1 = 1 minute

2 = 2 minutes

...

255 = 255 minutes (4h 15min)

The number of transmission cycles also affects the transmission of the measured values when jumper JP4 is closed. If set to 0, no transmission takes place.

**Routine 35: Dimension of the measured value**

The dimension is the physical size of the displayed measured value (e.g. m=milli,  $\mu$ =micro, p=Piko.... °=degree) The dimension does not appear in the display of the SPE670 but only in its printout. The dimension is entered as ASCII code decimal. For special characters (codes 128-256) the international code table from IBM (code page 437) is used.

Examples:

° = 248, m = 109, n = 110, p = 112

k = 107, M = 77, G = 71

**Routine 36: Naming the measured value**

The designation is the physical type of the displayed measured value (e.g. V=Volt, A=Ampere, ...C=Celsius) The designation does not appear in the display of the SPE670 but only in its printout. The designation is entered as ASCII code decimal. For special characters (codes 128-256) the international code table from IBM (code page 437) is used. Examples:

A = 65, C = 67, V = 86,  $\hat{U}$  = 234 (Ohm)

**Routine 37: User-defined character of the measured value**

The user-defined character extends the display to three characters, which allows information such as "Bar". The character does not appear in the display of the SPE670 but only in its printout. The character is entered as ASCII code decimal. For special characters (codes 128-256) the international code table from IBM (code page 437) is used.

Examples:

B - 66 in routine 35

a - 97 in routine 36

r - 114 in routine 37

m - 109 in routine 35

A - 65 in routine 36

- 32 in routine 37


Code table for routines 35, 36 and 37 See ASCII/special character table

**Jumper and start display**

Jumper JP4: If jumper JP4 is plugged in, measured values are transmitted via the serial interface in the set transmission cycle. Even if the interface is deactivated by routine 25. Routine 34 can be used to set the transmission cycles or to suppress transmission.

**11 Sub-D RS232 adapter**

The adapter is used to connect the device to a computer. The following pictures show how to connect the board to the device.



## 12 Technical data

Dimensions DIN 43700:	96 x 48 mm
Installation depth:	approx. 115 mm
Weight:	410 g
Working temperature:	-10 to +50° Celsius
Storage temperature:	-10 to +50° Celsius.
switching threshold:	programmable
Switching hysteresis:	programmable
Relay data:	2 x 230 VAC / 5 A
Mains supply:	230 V, 50-60 Hz, 3VA or 110 V, 50-60 Hz, 3VA, see type plate
Sensor output:	24 V / 30 mA DC
Working temperature:	0 to +40 °C
Storage temperature:	-10 to +40 °C
Humidity:	< 80 %, non-condensing

## 13 Radiation protection

UV radiation is harmful to humans, therefore observe the protective regulations when working. Furthermore, UVC radiation in particular has a material-destroying effect. It is therefore advisable not to expose the sensors to too much radiation. If possible, avoid - exceeding the measuring range in the least sensitive setting and use an aperture in good time.

If the thermal load caused by the radiators is too high, it may be useful to place a shielding hood over the sensors, which only exposes the receiver surface. This can significantly reduce the heating of the sensors.